

# Reaching Cisco router console port remotely

□

## Contents

- [1 Introduction](#)
- [2 Prerequisites](#)
- [3 Configuration](#)
  - [3.1 RS232 - RJ45](#)
  - [3.2 USB](#)
  - [3.3 PuTTY configuration](#)
  - [3.4 Console port](#)

## Introduction

This article describes how to connect to a console of another device (e.g., a Cisco router, Fortigate firewall, etc.)

## Prerequisites

You will need:

- A [RUT955](#) router
- An **RS232 (male) - RJ45** cable (to connect to a Cisco AUX port):  

- Or a **USB type Mini - USB type A** cable (to connect to a USB type mini console port):  


## Configuration

There are multiple ways to connect to a console port, which are described in the sections below:

### RS232 - RJ45

---

RS232 can be configured from the Services → RS232/RS485 → [RS232 Configuration](#) page. The following RS232 configuration should be used:



### USB

---

Using Mini USB - USB type A configuration. Configured from the WebUI, Services → [USB Tools](#) →

USB to Serial page:



## PuTTY configuration

---

The console can be accessed by using software such as **PuTTY** (can be downloaded from [here](#)).

The PuTTY configuration should look like this:



## Console port

---

Example of console ports:

