

Short Message Service Commands TRM240

[TRM240 AT Commands](#) > [TRM240 AT Commands](#) > [TRM240 AT Commands](#) > [TRM240 AT Commands](#) > [TRM240 AT Commands](#) > [TRM240 AT Commands](#) > [TRM240 AT Commands](#) > [TRM240 AT Commands](#) > [TRM240 AT Commands](#) > [TRM240 AT Commands](#) > [TRM240 AT Commands](#) > [TRM240 AT Commands](#) > [TRM240 AT Commands](#) > [TRM240 AT Commands](#) > **Short Message Service Commands TRM240**

□

Contents

- [1 Short Message Service Related Commands](#)
 - [1.1 AT+CSMS Select Message Service](#)
 - [1.2 AT+CMGF Message Format](#)
 - [1.3 AT+CSCA Service Center Address](#)
 - [1.4 AT+CPMS Preferred Message Storage](#)
 - [1.5 AT+CMGD Delete Message](#)
 - [1.6 AT+CMGL List Message](#)
 - [1.7 AT+CMGR Read Message](#)
 - [1.8 AT+CMGS Send Message](#)
 - [1.9 AT+CMMS More Message to Send](#)
 - [1.10 AT+CMGW Write Message to Memory](#)
 - [1.11 AT+CMSS Send Message from Storage](#)
 - [1.12 AT+CNMA New Message Acknowledgement to UE/TE](#)
 - [1.13 AT+CNMI SMS Event Reporting Configuration](#)
 - [1.14 AT+CSCB Select Cell Broadcast Message Types](#)
 - [1.15 AT+CSDH Show SMS Text Mode Parameters](#)
 - [1.16 AT+CSMP Set SMS Text Mode Parameters](#)
 - [1.17 AT+QCMGS Send Concatenated Messages](#)
 - [1.18 AT+QCMGR Read Cocatenated Messages](#)

Short Message Service Related Commands

[AT+CSMS Select Message Service](#)

The command selects messaging service **<service>** and returns the types of messages supported by the ME.

[AT+CMGF Message Format](#)

The command specifies the input and output format of the short messages. **<mode>** indicates the format of messages used with Test, Read, Write and Execution Commands and unsolicited result codes resulting from received messages.

The format of messages can be either PDU mode (entire TP data units used) or text mode (headers

and body of the messages given as separate parameters). Text mode uses the value of parameter **<chset>** specified by **AT+CSCS** command to inform the character set to be used in the message body in the TA-TE interface.

AT+CSCA Service Center Address

The Write Command updates the SMSC address when mobile originated SMS are transmitted. In text mode, the setting is used by Write Command. In PDU mode, setting is used by the same command, but only when the length of the SMSC address is coded into the **<pdu>** parameter which equals to zero

AT+CPMS Preferred Message Storage

The command selects the memory storages **<mem1>**, **<mem2>** and **<mem3>** to be used for reading, writing, etc.

AT+CMGD Delete Message

The command deletes short messages from the preferred message storage **<mem1>** location **<index>**. If **<delflag>** is presented and not set to 0, then the ME shall ignore **<index>** and follow the rules of **<delflag>** shown as below

AT+CMGL List Message

The Read Command returns messages with status value **<stat>** from preferred message storage **<mem1>** to the TE. If the status of the message is "REC UNREAD", the status in the storage changes to "REC READ". When executing command AT+CMGL without status value **<stat>**, it will report the list of SMS with "REC UNREAD" status.

AT+CMGR Read Message

The Read Command returns SMS message with location value **<index>** from message storage **<mem1>** to the TE. If status of the message is "REC UNREAD", status in the storage changes to "REC READ".

AT+CMGS Send Message

The Write Command sends a short message from TE to network (SMS-SUBMIT). After invoking the write command, wait for the prompt ">" and then start to write the message. After that, enter **<CTRL-Z>** to indicate the ending of PDU and begin to send the message. Sending can be cancelled

by giving **<ESC>** character. Abortion is acknowledged with **"OK"**, though the message will not be sent. The message reference **<mr>** is returned to the TE on successful message delivery. The value can be used to identify message upon unsolicited delivery status report result code

[AT+CMMS More Message to Send](#)

The command controls the continuity of the SMS relay protocol link. If the feature is enabled (and supported by the currently used network) multiple messages can be sent faster as the link is kept open.

[AT+CMGW Write Message to Memory](#)

The Write and Execution Commands store short messages from TE to memory storage **<mem2>**, and then the memory location **<index>** of the stored message is returned. Message status will be set to "stored unsent" by default, but parameter **<stat>** also allows other status values to be given.

The syntax of input text is the same as the one specified in **AT+CMGS** Write Command.

[AT+CMSS Send Message from Storage](#)

The Write Command sends messages with location value **<index>** from message storage **<mem2>** to the network. If a new recipient address **<da>** is given for SMS-SUBMIT, it shall be used instead of the one stored with the message.

[AT+CNMA New Message Acknowledgement to UE/TE](#)

The Write and Execution Commands confirm successful receipt of a new message (SMS-DELIVER or SMS-STATUS-REPORT) routed directly to the TE. If the UE does not receive acknowledgement within required time (network timeout), it sends an **RP-ERROR** message to the network. The UE will automatically disable routing to the TE by setting both **<mt>** and **<ds>** values of **AT+CNMI** to 0.

[AT+CNMI SMS Event Reporting Configuration](#)

The Write Command selects the procedure on how the received new messages from the network are indicated to the TE when TE is active, e.g. DTR is at low level (ON). If TE is inactive (e.g. DTR is at high level (OFF)), message receiving should be done as specified in 3GPP TS 23.038.

[AT+CSCB Select Cell Broadcast Message Types](#)

The Write Command selects which types of CBMs are to be received by the ME. The command writes the parameters in NON-VOLATILE memory.

[**AT+CSDH Show SMS Text Mode Parameters**](#)

The Write Command controls whether detailed header information is shown in text mode result codes

[**AT+CSMP Set SMS Text Mode Parameters**](#)

The command is used to set values for additional parameters needed when a short message is sent to the network or placed in a storage in text mode

[**AT+QCMGS Send Concatenated Messages**](#)

The command is used to send concatenated messages. Different from **AT+CMGS**, when sending a concatenated message via this command, each segment of the concatenated message must be identified by the additional parameters: **<uid>**, **<msg_seg>** and **<msg_total>**. When sending all segments of the message one by one, **AT+QCMGS** must be executed multiple times (equal to **<msg_total>**) for each segment. This command is only used in text mode (**AT+CMGF=1**).

[**AT+QCMGR Read Cocatenated Messages**](#)

The function of this command is similar to **AT+CMGR**, except that the message to be read is a segment of concatenated messages, and parameters **<uid>**, **<msg_seg>** and **<msg_total>** would be shown in the result. Several segments should be concatenated to a whole concatenated message according to these three parameters. Similar to **AT+QCMGS**, **AT+QCMGR** is only used in text mode (**AT+CMGF=1**).