

TSW212 Ports

[Main Page](#) > [TSW Switches](#) > [TSW212](#) > [TSW212 Manual](#) > [TSW212 WebUI](#) > [TSW212 Network section](#) > **TSW212 Ports**

The information in this page is updated in accordance with firmware version .

□

Contents

- [1 Summary](#)
- [2 General](#)
- [3 Port Settings](#)
 - [3.1 Port Settings](#)
 - [3.2 Port Status](#)
- [4 Port Mirroring](#)
- [5 Loopback Detection](#)
 - [5.1 Loopback Detection](#)
 - [5.2 Port Tracking](#)
- [6 Port Security](#)
 - [6.1 General](#)
 - [6.1.1 Port Settings](#)
 - [6.1.2 Port Status](#)
 - [6.2 RADIUS](#)
 - [6.2.1 Radius Configuration](#)

Summary

The **Ports** page provides information related to the status of the device's physical ports, as well as the ability to edit port settings, security, loopback detection.

General

In this section you can enable **Jumbo frames** and **LLDP frame filter** services.

✘

Field	Value	Description
Jumbo frames	off on; default: on	Allow ethernet frame with a payload greater than the standard maximum transmission unit (MTU) of 1500 bytes. This may improve network performance by making data transmissions more efficient.
LLDP frame filter	off on; default: off	Enable to stop the forwarding of LLDP frames.
IGMP snooping	off on; default: off	Enables IGMP snooping.
Multicast querier	off on; default: off	Enables multicast querier.

Port Settings

This section displays information about the status of the device's ports with the ability to configure port settings.

Port Settings

The figure below is an example of the **All Ports** window, color indicates port speed and status:



To change port settings select port and press `edit (number of ports) ports` button:



You will be redirected to `Port settings`. From here you can enable/disable ports or change settings:



Field	Value	Description
Enable	off on; default: on	Toggle port on or off.
EEE	off on; default: on	Enable Energy-Efficient Ethernet.
Isolate port	off on; default: off	When enabled port will be isolated from other isolated ports. Traffic between isolated ports will dropped. Traffic between isolated and normal ports will be sent as normal.
Link speed	Auto 10Mbps (E) 100Mbps (FE) 1000Mbps (GbE) ; default: Auto	A measure of how fast ports are able to transmit and receive data.
Duplex	Full Half; default:	Advertises preferred duplex mode and speed for negotiation with other devices.

Port Status

This section displays port status information. There is also an option to select, enable ports, enable/disable PoE, EEE and Isolation options:



Field Name	Description
Port	Port ID.
Enabled	Enable/Disable port.
Status	Port status.
Speed	Port link speed. • Possible speeds: • GbE: 1000Mbps • FE: 100Mbps • E: 10Mbps
PoE (W)	PoE port power usage in watts.
EEE	Enable/Disable Energy-Efficient Ethernet.
Isolation	When enabled port will be isolated from other isolated ports. Traffic between isolated ports will be dropped. Traffic between isolated and normal ports will be sent as normal.
TX sum	Total upload.
RX sum	Total download.
TX rate	Upload speed.

Port Mirroring

Port Mirroring is a service that mirrors incoming and outgoing packets on one Ethernet port (Source Port) to another (Monitoring Port).

To change port mirroring settings select port and press `Edit` button:



You will be redirected to `Port mirroring settings`, from here you can select ingress and egress ports:



Field	Value	Description
Enable	off on; default: off	The port which will mirror the packets.
Ingress mirroring port list	port; default: none	Specify which port incoming traffic is mirrored.
Egress mirroring port list	port; default: none	Specify which port outgoing traffic is mirrored.

Loopback Detection

Loopback Detection

A port-based loopback detection service that using its own distinctive packets, seeks to identify and break a network loop by shutting down troublesome ports.



Field	Value	Description
Enable	off on; default: off	Enable loopback detection.
Broadcast interval	integer [1..10000]; default: none	Send detection packets in an given interval from 1 to 10000 seconds.
Auto-recovery interval	integer [60..10000]; default: none	Restores disabled ports in an given interval from 60 to 10000 seconds.

Port Tracking

Tracks specific port status. **Notes:**

- STP:** STP must be disabled in Network -> Spanning Tree and loopback detection must be enabled for the service to function.
- Port unblocking:** When a loop occurs before a broadcast, it won't be recognized until the broadcast transmits its own packets, since the service only listens for packets with its own particular protocol.



To change port tracking setting press on port and you will be redirected to `Port tracking`

configuration` : 

Field	Value	Description
Enable	off on; default: on	Enable port tracking.
Recovery mode	Auto Manual; default: Auto	Manages port unblocking type. Possible modes: <ul style="list-style-type: none">• Manual: Port is blocked until manual unblock.• Auto: Unblocked automatically depending on the global Auto-recovery interval value.

Port Security

This section displays information about the status of the device's ports with the ability to configure port security settings.

General

Port Settings

The figure below is an example of the **Port Settings** window, color indicates port speed and status:



To change port security settings select port and press `edit (number of ports) ports` button:




You will be redirected to `Port security settings`. From here you can enable/disable ports or change security settings:



Field	Value	Description
Enable	off on; default: off	Enable security for port.
Radius sever	radius server ID; default: example	Radius server ID.
Radius unreachable action	Accept Reject; default: Accept	"Accept" gives anyone access to the port when the radius server is unreachable. "Reject" only unblocks the port if radius server explicitly authorizes it.
Fallback VLAN	Disabled VLAN; default: Disabled	Indicates fallback VLAN
Reject VLAN	Disabled VLAN; default: Disabled	Indicates reject VLAN
Accept VLAN	Radius assigned vlan1(ID: 1); default: vlan1(ID: 1)	Indicates accept VLAN

Port Status


This section displays port status information. There is also an option to select, enable ports security, choose RADIUS server and change RADIUS unreachable action:



Field Name	Description
Port	Port ID.
Enabled	Enables port security on this port.
Status	Port status.
Radius server	Authenticates and authorizes devices trying to connect to this port.
Radius unreachable action	"Accept" gives anyone access to the port when the radius server is unreachable. "Reject" only unblocks the port if radius server explicitly authorizes it.

RADIUS


The **RADIUS** page is used to create and manage radius servers:



Field Name	Description
ID	RADIUS server ID.
Address (IPv4)	RADIUS server IP.
Authentication port	RADIUS server authentication port.
Secret	RADIUS server secret.

Radius Configuration

The RADIUS configuration window should look similar to this:



Field	Value	Description
Address (IPv4/IPv6)	ip; default: 0.0.0.0	RADIUS server IP.
Authentication port	integer [1.. 65535]; default: 1812	RADIUS server authentication port.
Secret	string; default: -	RADIUS server secret.
Test connectivity	-(interactive) button	Test connectivity to RADIUS server.
Test user credentials	-(interactive) button	Test credentials to RADIUS server.
Enable backup RADIUS server	off on ; default: off	Enable backup RADIUS server.
Address (IPv4/IPv6)	ip; default: none	Backup RADIUS server IP.
Authentication port	integer [1.. 65535]; default: none	Backup RADIUS server authentication port.
Secret	string; default: -	Backup RADIUS server secret.
Test connectivity	-(interactive) button	Test connectivity to backup RADIUS server.
Test user credentials	-(interactive) button	Test credentials to backup RADIUS server.