

TRB145 Auto Reboot

[Main Page](#) > [TRB Gateways](#) > [TRB145](#) > [TRB145 Manual](#) > [TRB145 WebUI](#) > [TRB145 Services section](#) > **TRB145 Auto Reboot**

The information in this page is updated in accordance with firmware version [TRB1_R_00.07.04.5](#).



Contents

- [1 Summary](#)
- [2 Ping/Wget Reboot](#)
- [3 Reboot Scheduler](#)

Summary

Various automatic device reboot scenarios can be configured in the **Auto Reboot** section. Automatic reboots can be used as a prophylactic or precautionary measure that ensures the device will self-correct some unexpected issues, especially related to connection downtime.

This chapter is an overview of the Auto Reboot section of TRB145 devices.

If you're having trouble finding this page or some of the parameters described here on your device's WebUI, you should **turn on "Advanced WebUI" mode**. You can do that by clicking the "Basic" button under "Mode", which is located at the top-right corner of the WebUI.



MODE: BASIC | USER: ADMIN | FW VERSION: TRB1_R_00.07.00 | LOGOUT

Ping/Wget Reboot

The **Ping/Wget Reboot** functions periodically send ICMP or Wget requests to a specified IP address or host and waits for a response. If no response is received, the device will attempt the same action a defined number of times at a defined frequency. If there is still no response, the device will execute the specified action (reboot, by default).

The Ping/Wget Reboot section contains one pre-configured rule by default:

^ PING/WGET REBOOT SETTINGS

TYPE	ACTION	INTERVAL (MIN)	TIMEOUT (SEC)	TRY COUNT	HOST		
Ping	Reboot	5	5	2	8.8.8.8		

off on

ADD

SAVE & APPLY

To enable the default rule, use the off/on slider next to it. You can add more rules with the 'Add' button or delete them using the 'Delete' button. If you wish to customize a rule, click the button that looks like a pencil next to it.

PING/WGET REBOOT SETTINGS

Enable

No action on data limit

Type

Action if no echo is received

Interval

Interval count

Timeout (sec)

Packet size

Interface

IP type

Host to ping

SAVE & APPLY

Field	Value	Description
Enable	off on; default: off	Turns the rule on or off.
Type	Ping Wget; default: Ping	Method used for health checking. <ul style="list-style-type: none"> • Ping - sends ICMP requests to the specified host. • Wget - retrieves the contents of the specified web server.
Action if no echo is received	Device reboot None Modem reboot Restart mobile connection (Re)register Send SMS ; default: Device reboot	Action that will be executed if there is no response after the specified amount of retries. If None is selected, only a message to syslog will be logged.
Phone Number	phone number(s); default: none	Recipient's phone number(s) specified in international format.
Message text	string; default: none	Text to be included in the SMS message.
Interval	5 mins 15 mins 30 mins 1 hour 2 hours; default: 5 mins	The frequency at which ping/Wget requests are sent to the specified host.
Interval count	integer [1..9999]; default: 2	Indicates how many additional times the device will try sending requests if the initial one fails.
Timeout (sec)	integer [1..9999]; default: 5	Maximum response time. If no echo is received after the amount of time specified in this field has passed, the ping/wget request is considered to have failed.
Packet size	integer [0..1000]; default: 56	ICMP packet size in bytes.
Interface	Automatically selected Ping from mobile ; default: Automatically selected	Specifies through which interface the pings will be sent. If Automatically selected is set, the pings will go through the main WAN interface.
IP type	IPv4 IPv6; default: IPv4	IP address version of the host to ping.

Host to ping host | ip; default: **8.8.8.8**

Host to ping from SIM 1 ip; default: **8.8.8.8**

Hostname or IP address to which the Ping/Wget requests will be sent.



IP address to which the Ping requests will be sent on SIM 1.

Reboot Scheduler

The **Reboot Scheduler** is a function that reboots the device at a specified time interval regardless of other circumstances. It can be used as a prophylactic measure, for example, to reboot the device once at the end of every day.

You can add more rules with the 'Add' button or delete them using the 'Delete' button. If you wish to customize a rule, click the button that looks like a pencil next to it.

^ REBOOT SCHEDULER

ACTION	DAYS	TIME		
Reboot	Mon	12:00	 	<input type="checkbox"/> off <input type="checkbox"/> on

[ADD](#)

[SAVE & APPLY](#)


The figure below is an example of the Periodic Reboot configuration page and the table below provides information on the fields contained in that page:

∨ REBOOT SCHEDULER

Enable off on

Action

Week Days

Day time (hh:mm) 

[SAVE & APPLY](#)

Field	Value	Description
Enable	off on; default: off	Turns the rule on or off.
Action	Device reboot Modem reboot; default: Device reboot	Action that will be executed at the specified time.
Interval type	Week days Month days ; default: Week days	Scheduler instance interval type.
Week days	Monday Tuesday Wednesday Thursday Friday Saturday Sunday; default: Monday	Week day(s) when actions will be executed. This field becomes visible when Interval type is set to Week days.
Month day	integer [1..31]; default: 1	Day of the month on which the reboot will occur. This field becomes visible when Interval type is set to Month days.
Month	month(s) [january..december]; default: none	The month(s) on which the reboot will occur. Leave empty to apply to all months. This field becomes visible when Interval type is set to Month days.

Day time time [00:00..23:59]; default: **none**

Exact time of day the reboot will take place

Force last
day off | on; default: **off**

Forces intervals to accept last day of month as a valid option if selected day doesn't exist in the ongoing month. This field becomes visible when Interval type is set to Month days.