

# Template:Networking rut9xx manual mobile

□

## Contents

- [1 Summary](#)
- [2 General](#)
  - [2.1 Mobile Configuration](#)
  - [2.2 Mobile data on demand](#)
  - [2.3 Passthrough mode](#)
  - [2.4 Bridge mode](#)
- [3 SIM Management](#)
  - [3.1 Primary card](#)
  - [3.2 SIM Switching](#)
    - [3.2.1 SIM switching rules](#)
- [4 Network Operators](#)
  - [4.1 Scan For Network Operators](#)
  - [4.2 Operators List](#)
- [5 Mobile Data Limit](#)
  - [5.1 Data Connection Limit Configuration](#)
  - [5.2 SMS Warning Configuration](#)
  - [5.3 Clear Data Limit](#)
- [6 SMS Limit](#)
  - [6.1 SMS Limit Configuration](#)
  - [6.2 Clear SMS Limit](#)
- [7 SIM Idle Protection](#)
  - [7.1 Settings](#)
  - [7.2 Test](#)

## Summary

The **Mobile** page is used for setting parameters related to the mobile data connection. This page is an overview of the Mobile section for `{{name}}` routers.

All of the examples given below are concerning SIM1. However, SIM2 configuration is identical to SIM1. To configure SIM2 all you need to do is select the SIM2 tab. This is true for all cases in the *Network* → *Mobile* section of the router's WebUI (General, SIM Management, etc.)

The information in this page is updated in accordance with the [\[\[Media:{{{fw\\_version}}}\\_WEBUI.bin|{{{fw\\_version}}}\]\]](#) firmware version.

## General

The **General** section is used to configure the SIM card parameters that define how the router establishes a cellular connection.

## Mobile Configuration

---

The **Mobile Configuration** section is used to configure main SIM card parameters. Refer to the figure and table below for information on the fields contained in that section.

[[File:{{{file\_general\_configuration}}}}]]

Field	Value	Description
Connection type	QMI   PPP; default: <b>QMI</b>	<p>How the router's modem will establish a connection to the carrier.</p> <ul style="list-style-type: none"><li>• <b>PPP</b> - uses a dialling number to establish a data connection.</li><li>• <b>QMI</b> - does not use a dialling number to connect and is usually faster than PPP.</li></ul>
Mode	NAT   Bridge *   Passthrough**; default: <b>NAT</b>	<p>Mobile connection operating mode.</p> <ul style="list-style-type: none"><li>• <b>NAT</b> - the mobile connection uses NAT (network address translation).</li><li>• <b>Bridge</b> - bridges the LTE data connection with LAN. In this mode the router relay the IP address received from the ISP to another LAN device (e.g., computer). Using Bridge mode will disable most of the router's capabilities and you will only be able to access your router's WebUI with a <a href="#">static IP configuration</a>.</li><li>• <b>Passthrough</b> - works in a similar fashion to Bridge mode, except in Passthrough mode the router will have an Internet connection and be reachable from LAN, because the router's DHCP Server is not disabled.</li></ul>
APN	string; default: <b>none</b>	<p>An Access Point Name (APN) is a gateway between a GSM, GPRS, 3G or 4G mobile network and another computer network. Depending on the contract, some operators may require you to use an APN just to complete the registration on a network. In other cases, APN is used to get special parameters from the operator (e.g., a <a href="#">public IP address</a>) depending on the contract.</p> <p>An APN Network Identifier cannot start with any of the following strings:</p> <ul style="list-style-type: none"><li>• rac;</li><li>• lac;</li><li>• sgsn;</li><li>• rnc;</li></ul> <p>it cannot end in:</p> <ul style="list-style-type: none"><li>• .gprs;</li></ul> <p>and it cannot contain the asterisk symbol (*).</p>
Auto APN	checkbox; default: <b>enabled</b>	<p>Auto APN scans an internal Android APN database and selects an APN based on the SIM card's operator and country. If the first automatically selected APN doesn't work, it attempts to use the next existing APN from the database.</p>
PIN number	string; default: <b>none</b>	<p>A 4-digit long numeric password used to authenticate the modem to the SIM card. <b>Reminder: Firstboot will not reset the PIN number, it must be changed manually</b></p>

PUK number	string; default: <b>none</b>	A 12-digit long numeric password used to reset a personal identification number (PIN) that has been lost or forgotten.
Dialing number	string; default: <b>none</b>	A <a href="#">dial code</a> used to establish a mobile PPP connection.
MTU	integer [0..1500]; default: <b>1500</b>	Sets the maximum transmission unit (MTU) size. It is the largest size of a protocol data unit (PDU) that can be transmitted in a single network layer transaction.
Authentication method	CHAP   PAP   None; default: <b>None</b>	Authentication method that your GSM carrier uses to authenticate new connections on its network. If you select PAP or CHAP, you will also be required to enter a username and password.
Service mode	2G only   3G only 4G (LTE) only   Automatic; default: <b>Automatic</b>	Your service mode preference. If your local mobile network supports 2G, 3G and 4G (LTE), you can specify to which type of network you wish to connect to. For example, if you choose 2G only, the router will connect to a 2G network, so long as it is available, otherwise it will connect to a network that provides better connectivity. If you select Automatic, then the router will connect to the network that provides the best connectivity.
Deny data roaming	yes   no; default: <b>no</b>	When enabled, this option prevents the device from establishing a mobile data connection while not in your home network (roaming conditions).
Use IPv4 only	yes   no; default: <b>yes</b>	When enabled, this makes the device only use IPv4 settings for the mobile connection.

\* more on Passthrough mode in [section 2.3](#) of this page.

\*\* more on Bridge mode in [section 2.4](#) of this page.

## Mobile data on demand

---

The **mobile data on demand** function keeps the mobile data connection *on* only when it is in use. When the router detects that there is no traffic, it shuts down the mobile data connection and turns it back *on* only when there is a "Demand" (a user trying to reach a website, for example). Refer to the figure and table below for more information.

[[File:{{{file\_general\_demand}}}}]]

Field	Value	Description
Enable	yes   no; default: <b>no</b>	Turns mobile data on demand on or off <b>Important:</b> this function is only available with PPP Connection type.
No data timeout (sec)	integer [10..3600]; default: <b>10</b>	Mobile data connection will be terminated if no data is transferred during the timeout period specified in this field.

## Passthrough mode

---

In **Passthrough** mode the router assigns its mobile WAN IP address to another device. It is similar to *Bridge* mode, except in Passthrough mode other devices can still connect to the router and get LAN IP addresses and both other clients and the router retain Internet access, while Bridge mode also disables the router's DHCP Server.

To begin configuring Passthrough mode, make sure that WAN failover is turned off and mobile is set as main WAN in the *Network* → *[[{{{name}}}] WAN|WAN]]* page. Then in the *Network* → *Mobile* page select *Mode: Passthrough* in the mobile configuration section. You will then see additional configuration fields appear at the bottom of the section.

**Important:** using Passthrough mode will disable most of the router's other capabilities.

[[File:{{{file\_passthrough}}}]]

Field	Value	Description
DHCP mode	Static   Dynamic   No DHCP; default: <b>Static</b>	Specifies DHCP mode used with Passthrough. <ul style="list-style-type: none"> <li>• <b>Static</b> - manually binds the WAN IP address to the device with the specified MAC address. This device will get an IP address from your GSM operator. Other devices that are connected to the router will get IP addresses from the router's DHCP server, but they will not have internet access.</li> <li>• <b>Dynamic</b> - the GSM operator will connect to the router first and give out an IP address to one of your connected devices. The device will be selected at random. Therefore, you should usually use Dynamic mode when you have only one device (e.g., computer) connected to the router. When using Passthrough in Dynamic mode, the router's LAN DHCP server will be disabled, but it will be enabled again automatically when you switch to a different mode.</li> <li>• <b>No DHCP</b> - IP address, subnet mask, default gateway and DNS information from the GSM operator will have to be entered on your computer manually. When using Passthrough in No DHCP mode, the router's LAN DHCP server will be disabled, but it will become enabled automatically when you switch to a different mode.</li> </ul>
MAC address	mac; default: <b>none</b>	MAC address of a LAN device (e.g., computer).

## Bridge mode

---

In **Bridge** mode the router assigns its WAN IP address to another device. It is used instead of [Network Address Translation](#) (NAT) in order to make the router "transparent" in the communication process. The main difference between Passthrough and Bridge is that in Passthrough, the router's DHCP Server still works and the regular LAN interface is still up, allowing clients to connect to the router's local network as usual, while Bridge mode disables all of these features and simply gives the a single specified device its WAN IP address. Since Bridge uses less of the router's features, it is a bit faster than Passthrough.

To begin configuring Bridge mode, make sure that WAN failover is turned off and mobile is set as main WAN in the *Network* → *[[{{{name}}}] WAN|WAN]]* page. Then in the *Network* → *Mobile* page select *Mode: Bridge* in the mobile configuration section. You will then see an additional configuration field for entering a MAC address appear *Mode* field.

**Important:** using Bridge mode will disable most of the router's other capabilities.

```
[[File:{{{file_bridge}}}]]
```

Field	Value	Description
Bind to MAC	mac; default: <b>none</b>	Specifies the MAC address of the device that will work with the router in Bridge mode, i.e., the device whose MAC is specified in this field will be assigned the router's Mobile WAN IP address.

If you have configured Bridge mode and can no longer reach your router, you'll need to set up a Static IP address on your PC in order to do so. If you don't know how to set up a Static IP, you can use one of our "how to" guide on this subject:

- [Windows guide](#)
- [Linux guide](#)

## SIM Management

The **SIM Management** section provides you with the possibility to specify which SIM card slot is the primary one and setup SIM switching rules. SIM switching is used as a failover mechanism when the user has two working SIM cards. For example, if the user has two SIM cards with limited data, you can setup a rule that switches the SIM card in use to the secondary SIM card when the data limit is reached. You can setup similar rules for SMS limit, signal strength and more.

### Primary card

---

The **Primary card** section is used to select which SIM slot will host the router's primary SIM card. The primary SIM card is the one which is active by default, while the secondary card stays inactive until switched to or set as primary.

```
[[File:{{{file_sim_management_card}}}]]
```

**Note:** both SIM cards cannot be active at the same time.

### SIM Switching

---

The **SIM switching** section is used to enable automatic SIM switching and to set the SIM switching check interval. Refer to the figure and table below for more information.

```
[[File:{{{file_sim_management_switching}}}]]
```

Field	Value	Description
Enable automatic switching*	yes   no; default: <b>no</b>	Turns automatic SIM Switching on or off.

Check interval	integer; default: <b>30</b>	The frequency at which the router will check for condition changes corresponding to SIM switch rules. If such a condition exists, the router will perform a SIM switch, if not - it will check for the same conditions again after the amount of time specified in this field.
----------------	--------------------------------	--

## SIM switching rules

---

Below the SIM switching section you can configure **SIM switching rules**, i.e., set up circumstances under which the router will perform a switch from using one SIM card to the other. Refer to the figure and table below for information.

[[File:{{{file\_sim\_management\_conditions}}}}]]

Field	Value	Description
On weak signal	yes   no; default: <b>no</b>	Performs a SIM switch when signal strength value ( <a href="#">RSSI</a> in dBm) falls below a specified threshold. When this field is checked you will see an additional field for entering the minimum signal strength value appear.
On data limit	yes   no; default: <b>no</b>	Performs a SIM switch when the SIM card reaches the specified data limit for the designated period. Mobile data limit can be configured in the Services → Mobile → <a href="#">Mobile Data Limit</a> page.
On SMS limit	yes   no; default: <b>no</b>	Performs a SIM switch when the SIM card reaches the specified sent SMS limit for the designated period. SMS limit can be configured in the Services → Mobile → <a href="#">SMS Limit</a> page.
On roaming	yes   no; default: <b>no</b>	Performs a SIM switch when roaming conditions are detected (i.e., when the SIM card connects to a foreign operator).
No network	yes   no; default: <b>no</b>	Performs a SIM switch when the SIM card cannot find an operator to connect to.
On network denied	yes   no; default: <b>no</b>	Performs a SIM switch when access to a network is denied (usually by an operator).
On data connection fail	yes   no; default: <b>no</b>	Performs a SIM switch when the router does receive an LCP or ICMP echo from a specified host address.

**Note:** remember to check the *Enable automatic switching* field above in order to make you SIM switching rules work.

## Network Operators

The **Network Operators** tab provides you with the possibility to scan for and manually manage mobile network operators to which the router's SIM card can connect to. Operator selection is only available for the primary SIM card. In order to specify an operator for the other SIM card it must first be selected as the primary SIM in the [SIM Management](#) section.

### Scan For Network Operators

---

**Scan For Network Operators** is a function that initiates a scan for mobile network operators

available in your area. To initiate a scan, press the 'Scan for operators' button. After you do, you will be prompted with a pop-up asking if you wish to proceed. This is because while the scan is in progress you will lose your data connection for approximately 2 minutes.

[[File:{{{file\_network\_operators\_scan}}}]]

After the scan is complete you will be presented with a list of operators available in your area. The list provides such information as operator's name, code and network access type. You can also choose to which operator you would like to connect provided that the operator's status is not *Forbidden*.

---

Below the list you can select how to the router should connect to network operators:

[[File:{{{file\_network\_operators\_settings}}}]]

The 'Connection mode' specifies the logic of how the router will connect operators:

- **Auto** - the router automatically connects to the network operator that provides the best connectivity.
- **Manual** - prompts you to enter an operator's code\*. The router will then only attempt to connect to the operator whose code was specified (even if previous attempts have been unsuccessful).
- **Manual-Auto** - prompts you to enter an operator's code\* but if the router can't complete the connection, it will automatically connect to the next available operator.

\* Most network operators' codes can be found online or you can initiate a scan for operators - if the operator you're looking for can be reached from your current area, the list of available network operators will contain the desired operator's code.

## Operators List

---

The **Operators List** section is used for creating a blacklist or whitelist for undesired or desired operators. Please note that when using either Whitelist mode or Blacklist mode, you will initially lose your mobile connection for several minutes. Also if you have your SIM card set to switch "On network denied", your SIM card may switch when using Blacklist mode

### Settings

[[File:{{{file\_operator\_list\_settings}}}]]

Field	Value	Description
Enable yes   no; default: <b>no</b>		Turns operator list on or off.

Mode	Blacklist   Whitelist; default: <b>Whitelist</b>	<p>Defines how operators will be filtered.</p> <ul style="list-style-type: none"> <li>• <b>Blacklist</b> - operators contained in the blacklist are considered forbidden and your router will not attempt to connect to them even if they are available.</li> <li>• <b>Whitelist</b> - operators contained in the whitelist will be the only operators that the router will be trying to connect to. Other operators that are not in the whitelist will be considered forbidden.</li> </ul>
------	---	---

## Operators List

[[File:{{{file\_operator\_list}}}]]

Field	Value	Description
Name	string; default: <b>none</b>	Operator's name. Used only for easier management purposes and not in the actual filtering process.
Operator code	integer; default: <b>none</b>	Operator's code used to identify a network operator. You can find network operator codes online or use the router's scan for operators function described <a href="#">here</a> .

**Important:** be mindful when using the Operators List function as it very easy to block yourself from the right operators and lose your data connection.

## Mobile Data Limit

The **Mobile Data Limit** page provides you with the possibility to set data usage limits for your SIM cards and data usage warnings via SMS message in order to protect yourself from unwanted data charges.

Video tutorial - [How to Set Mobile Data Limit on Teltonika RUT9XX](#)

## Data Connection Limit Configuration

The **Data Connection Limit Configuration** section is used to configure custom mobile data limits for your SIM card(s). When the mobile data limit set for the SIM card(s) is reached, the router will no longer use the mobile connection to establish a data connection until the limit period is over or the limit is reset by the user.

[[File:{{{file\_data\_limit\_configuration}}}]]

Field	Value	Description
Enable data connection limit	yes   no; default: <b>no</b>	Turns mobile data limitations on or off.



Data limit* (MB)	integer; default: <b>none</b>	<p>The amount of data that is allowed to be downloaded over the specified period of time. When the limit is reached, the router will no longer be able to establish a data connection until the period is over or the data limit is reset.</p> <p><b>Note:</b> after the router has reached the data limit it will not switch to using the secondary SIM card. If you wish to configure a SIM switch system based on received data limit, instructions can be found in the <a href="#">SIM Switching rules</a> section of this page.</p>
Period	Month   Week   Day; default: <b>Month</b>	Data limit period after which the data counter is reset on the specified <i>Start day</i> .
Start day   Start hour	day [1..31]   day [Monday..Sunday]   hour [1..24]; default: <b>day 1</b>	Specifies when the period of counting data usage should begin. After the period is over, the limit is reset and the count begins over again.

\*Your carrier's data usage accounting may differ. Teltonika is not liable should any accounting discrepancies occur.

## SMS Warning Configuration

---

The **SMS Warning Configuration** section provides you with the possibility to configure a rule that sends you an SMS message after the router's SIM card(s) uses a specified amount of mobile data.

[[File:{{{file\_data\_limit\_warning}}}]]

Field	Value	Description
Enable SMS warning	yes   no; default: <b>no</b>	Toggles SMS warning On or OFF
Data limit* (MB)	integer; default: <b>none</b>	The received data limit before sending an SMS warning. After reaching using the the amount of data specified in this field, the router will send an SMS warning message to the specified phone number.
Period	Month   Week   Day; default: <b>Month</b>	Period to which the data limit applies to.
Start day   Start hour	day of the month [1..31]   day of the week [Monday..Sunday]   hour of the day [1..24]; default: <b>1</b>	Specifies when the period of counting data usage should begin. After the period is over, the limit is reset and the count begins over again.
Phone number	phone number; default: <b>none</b>	Recipient's phone numbers

## Clear Data Limit

---

The **Clear Data Limit** section contains only one button - 'Clear data limit'. When clicked, the button resets the data limit counter for the related SIM card. Thus, the count is started over again regardless of the specified period.

[[File:{{{file\_data\_limit\_clear}}}]]

**Important:** remember that the 'Clear data limit' button doesn't clear the actual data usage statistics for the SIM card, only the data counters as calculated by the router.

## SMS Limit

The **SMS Limit** page provides you with the possibility to set up a limit of SMS messages that the router's SIM card(s) can send in a period of one day, week or a month.

### SMS Limit Configuration

---

The **SMS Limit Configuration** section is used to configure custom SMS limits for your SIM card(s). In order to limit sent SMS messages, select the SIM card (SIM1 or SIM2), enable SMS limit and configure the limit conditions. For related information, refer to the figure and table below.

[[File:{{{file\_sms\_limit\_config}}}]]

Field	Value	Description
Enable SMS limit	yes   no; default: <b>no</b>	Turns SMS limitations on or off.
Period	Month   Week   Day; default: <b>Month</b>	SMS limit period after which the sent SMS counter is reset on the specified <i>Start day</i> .
Start day   Start hour	day of the month [1..31]   day of the week [Monday..Sunday]   hour of the day [1..24]; default: <b>1</b>	Specifies when the period of counting SMS messages should begin. After the period is over, the limit is reset and the count begins over again.
SMS limit*	integer; default: <b>none</b>	Number of SMS messages that the SIM card is allowed to send over the specified period of time. When the limit is reached, the router will no longer be able to send SMS messages until the period is over or the SMS limit is reset. <b>Note:</b> after the router has reached the SMS limit it will not switch to using the secondary SIM card. If you wish to configure a SIM switch system based on sent SMS limit, instructions can be found in the <a href="#">SIM Switching rules</a> section of this page.

\* Your carrier's SMS usage accounting may differ. Teltonika is not liable should any accounting discrepancies occur.

### Clear SMS Limit

---

The **Clear SMS Limit** section displays the amount of sent SMS messages and provides the possibility to reset that counter. When the 'Clear SMS button' is clicked, it clears the SMS limit counter for the related SIM card. Thus, the count is started over again regardless of the specified period.

[[File:{{{file\_sms\_limit\_clear}}}]]

**Important:** remember that the 'Clear SMS limit' button doesn't clear the actual sent SMS statistics

for the SIM card, only the SMS counters as calculated by the router.

# SIM Idle Protection

Some operators block user SIM cards after a period of inactivity. The **SIM Idle Protection** tab provides you with the possibility to configure the router to periodically switch to the secondary SIM card and establish a data connection with a mobile network operator in order to break the idleness and prevent the SIM card from being blocked.

## Settings

---

The **Settings** tab is used to configure the parameters used by the SIM Idle Protection function. Refer to the figure and table below for more information.

[[File:{{{file\_sim\_idle\_settings}}}]]

Field	Value	Description
Enable	yes   no; default: <b>no</b>	Turns SIM Idle Protection on or off.
Period	Month   Week; default: <b>Month</b>	How often SIM Idle Protection will be performed. Use the three following fields ('Day', 'Hour' and 'Minute') to set the exact time of the action.
Host to ping	ip; default: <b>127.0.0.1</b>	IP address of a host that will be pinged during the SIM Idle Protection action.
Ping package size	integer [1..1000]; default: <b>56</b>	ICMP packet size in bytes.
Ping requests	integer [1..30]; default: <b>2</b>	How many ping requests will be sent.

## Test

---

Once you have configured the SIM Idle Protection settings, you can use the **Test** section to test these settings to make sure everything works correctly. Once you click the 'Test' button, the SIM Idle Protection test will initiate. The test is designed to simulate SIM Idle Protection according to your current SIM Idle Protection settings.

[[File:{{{file\_sim\_idle\_test}}}]]

---

The test takes about 2 minutes, so make sure the router isn't doing anything important before you start the test because during it you will lose connectivity. It is very important to **wait for the test to finish before committing any actions**. Committing actions on the router during test phase you may cause the router to crash.

[[Category:{{{name}}} Network section]]