RUT361 Configuration Examples

This page contains various configuration guides for the RUT361 router. Unlike the articles in the **RUT361 Manual**, which provide more general knowledge on all of the router's features and functions, these guides are more in-depth and are usually focused on specific configuration scenarios with extensive explanations. While most of the guides apply to both Windows and Linux Operating Systems, some are exclusive to one OS and others aren't OS specific in any way and apply to any system.

☐

Contents

VPN

- ZeroTier
- Stunnel configuration example using Telnet
- Overlapping subnets with IPsec solution

Router control & configuration

- Blocking Internet Access for LAN Clients

Connection backup

- VRRP configuration

Third-party IoT platforms

- [Cumulocity](#)

DDNS

- [RUTX Noip.com DDNS configuration](#)
- [RUTX Dynu.com DDNS configuration](#)

LAN

- [Setting up a PPPoE between RUTX and Mikrotik device](#)
- [Setting up WAN as LAN](#)

Camera

- [Camera access from VPN](#)
- [Camera access from VPN RUTOS](#)
- [Camera access from smartphone](#)
- [Remote camera access](#)

PC

- [Wake on LAN PC setup (Windows)](#)

Third-party services

IoT platforms

- [Azure IoT Hub Cloud Connection](#)
- [da³vid](#)
- [BAG·Tower](#)

WiFi

- [Guglielmo LUMEN® AAA WiFi Setup](#)
- [RUTOS relay / Wi-Fi extender / repeater / bridge configuration](#)
- [ironwifi.com (Legacy firmware)](#)
- [ironwifi.com (RutOS firmware)](#)
- [cobot.me (Legacy firmware)](#)
- [cobot.me (RutOS firmware)](#)

Use cases

- [Reaching your home network remotely with your Android device](#)
- [Bridged office network with a separate Guest WiFi](#)

I/O Juggler

- [SMS and Email alerts Triggered by BAT120](#)

DHCP Relay

- [DHCP Relay configuration example](#)