

# Device Recovery Options

[Main Page](#) > [FAQ](#) > [Troubleshooting & Recovery](#) > **Device Recovery Options**

If your device has become unreachable through conventional methods, you may need to perform a restore to factory settings in order to get it working again. Please refer to the links below for information on how to recover your device.

## **RUT Routers**

- [RUT230](#)
- [RUT240](#)
- [RUT850](#)
- [RUT900](#)
- [RUT950](#)
- [RUT955](#)

## **RUTX Routers**

- [RUTX08](#)
- [RUTX09](#)
- [RUTX10](#)
- [RUTX11](#)
- [RUTX12](#)
- [RUTXR1](#)

## **TRB Gateways**

- [TRB140](#)
- [TRB141](#)
- [TRB142](#)
- [TRB145](#)
- [TRB245](#)
- [TRB255](#)