

# RUT140 LEDs

[Main Page](#) > [RUT Routers](#) > [RUT140](#) > [RUT140 Manual](#) > **RUT140 LEDs**

This page contains information the different types of LEDs and their behaviour on a RUT140 device.



## Contents

- [1 Power LED](#)
- [2 Ethernet port LEDs](#)

## Power LED

The **power LED** is located on the bottom left corner of the front panel, just under the power connector.



It indicates whether the device is powered on or not.

	State	Description
LED turned on		Device is powered on.
LED turned off		Device is not powered on.

## Ethernet port LEDs

The **Ethernet port LEDs** are located on the device's front panel, under each respective Ethernet port.



	State	Description
LED on		Operating as a 10/100 Mbps connection.
LED off		No link established.
LED blinking		Connection established and there is activity on this port (data being transferred).