

RUT230 Logs

[Main Page](#) > [RUT Routers](#) > [RUT230](#) > [RUT230 Manual](#) > [RUT230 WebUI](#) > [RUT230 Status section](#) > **RUT230 Logs**

The information in this page is updated in accordance with firmware version [RUT2_R_00.07.03.4](#).

Notice: This device has entered it's EOL (End of Life) cycle. For more information, visit our EOL policy [here](#). Temporarily, some content in this page might not match features found in firmware listed above.

Note: [click here](#) for the old style WebUI (FW version RUT2XX_R_00.01.14.7 and earlier) user manual page.

Contents

- [1 Summary](#)
- [2 Events Log](#)
- [3 Traffic Log](#)
- [4 Hotspot Log](#)

Summary

The **Logs** section contains information on various device related events. This article is an overview of the Logs section for RUT230 routers. If you're having trouble finding this page or some of the parameters described here on your device's WebUI, you should **turn on "Advanced WebUI" mode**. You can do that by clicking the "Advanced" button, located at the top of the WebUI.

Events Log

The **Events Log** section contains a chronological list of various events related to the device. The figure below is an example of the Events Log page:

Traffic Log

The **Traffic Log** section displays traffic which goes through one of the WAN interfaces. The device does collect data for the Traffic Log by default. To see Traffic Log information you must first enable Traffic Logging from the Services → [Traffic Logging](#) page.

The figure below is an example of the Traffic Log.

Hotspot Log

The **Hotspot Log** section displays Hotspot user information. The figure below is an example of the Hotspot Log.

