

# RUT230 Overview (legacy WebUI)

[Main Page](#) > [RUT Routers](#) > [RUT230](#) > [RUT230 Manual](#) > [RUT230 Legacy WebUI](#) > [RUT230 Status section \(legacy\)](#) > **RUT230 Overview (legacy WebUI)**

The information in this page is updated in accordance with firmware version [RUT2XX\\_R\\_00.01.14.7](#).

**Notice:** This device has entered it's EOL (End of Life) cycle. For more information, visit our EOL policy [here](#). Temporarily, some content in this page might not match features found in firmware listed above.

**Note:** this user manual page is for RUT230's old WebUI style available in earlier FW versions. [Click here](#) for information based on the latest FW version.

□

## Contents

- [1 Summary](#)
- [2 Overview](#)
  - [2.1 Mobile widget](#)
  - [2.2 Widget button: Info](#)
  - [2.3 Widget button: Settings](#)
  - [2.4 Widget button: Wiki](#)
  - [2.5 Adding more widgets](#)

## Summary

The **Overview** page contains various information summaries and shortcuts to other pages. It is also the homepage of the WebUI. This chapter is an overview of the Overview page for RUT230 devices.

## Overview

The Overview page contains **widgets** that display the status of various systems related to the device. The figure bellow is an example of the Overview page:

✘

### Mobile widget

---

The **Mobile** widget displays information related to the mobile connection and the current **signal strength** (✘). Each filled-up bar represents a different RSSI value:


**bars**      **signal strength value / RSSI (in dBm)**

0	$\leq -111$
1	-110 to -97
2	-96 to -82
3	-81 to -67
4	-66 to -52
5	$\geq -51$

The same calculation principle applies to the **Signal strength LEDs** located on your device. You can find more information on signal strength values and different measurements [here](#).

## Widget button: Info

---

The **Info** () button is located next to the name of some widgets. Clicking the Info button redirects the user to a status page related to the widget's displayed information. For example, clicking the Info button on the Mobile widget would redirect the user to the **Status** → [System](#) page:



## Widget button: Settings


---

The **Settings** button is located next to the name of some widgets. Clicking the Settings button redirects the user to a configuration page related to the widget's displayed information. For example, clicking the Info button on the Mobile widget would redirect the user to the *Network* → *Interface* → *LAN Configuration* page:



## Widget button: Wiki

---

The **Wiki** () button is located on the right of the title of some widgets. Clicking the Wiki button redirects the user to a page on this Wiki related to the widget's displayed information. For example, clicking the Wiki button on the RMS widget would redirect the user to the [RMS](#) page on this Wiki:



## Adding more widgets

---

There is a default set of widgets displayed in the Overview page, but more can be added from the **System** → **Administration** → [Overview](#) page.