

# RUT230 Services (legacy WebUI)

[Main Page](#) > [RUT Routers](#) > [RUT230](#) > [RUT230 Manual](#) > [RUT230 Legacy WebUI](#) > [RUT230 Status section \(legacy\)](#) > **RUT230 Services (legacy WebUI)**

The information in this page is updated in accordance with firmware version [RUT2XX\\_R\\_00.01.14.7](#).

**Notice:** This device has entered it's EOL (End of Life) cycle. For more information, visit our EOL policy [here](#). Temporarily, some content in this page might not match features found in firmware listed above.

**Note:** this user manual page is for RUT230's old WebUI style available in earlier FW versions. [Click here](#) for information based on the latest FW version.

□

## Contents

- [1 Summary](#)
- [2 Services](#)

## Summary

The **Services** page is used for easy service management. From here you can monitor your device's services states. Click a button to access respective section where it was originally configured.

This chapter of the user manual provides an overview of the Services page for RUT230 devices.

## Services

The **Services** page displays the status of most of the device's services. Services that are currently inactive are displayed in a red font, while active ones are highlighted in green.

The figure below is an example of the Services page:



Click the zone next to a service where it says "Change settings" and you will be redirected to configuration page.

### Additional notes:

- By default, only [NTP](#) and [SMS Utilities](#) services are enabled
- Some services have to be installed via [Package Manager](#), before they can be visible.