

[https://wiki.teltonika-networks.com/view/RUT955_CLI_\(legacy_WebUI\)](https://wiki.teltonika-networks.com/view/RUT955_CLI_(legacy_WebUI))

RUT955 CLI (legacy WebUI)

[Main Page](#) > [RUT Routers](#) > [RUT955](#) > [RUT955 Manual](#) > [RUT955 Legacy WebUI](#) > [RUT955 Services section \(legacy\)](#) > **RUT955 CLI (legacy WebUI)**

The information in this page is updated in accordance with firmware version [RUT9XX_R_00.06.09.5](#).

Note: this user manual page is for RUT955's old WebUI style available in earlier FW versions. [Click here](#) for information based on the latest FW version.

□

Contents

- [1 Summary](#)
- [2 CLI](#)

Summary

The **CLI** or **Command Line Interface** functionality allows you to enter and execute Linux commands within the router.

This chapter of the user manual provides an overview of the CLI page for RUT955 devices.

CLI

CLI is a console interface similar to the Linux Terminal program. Use the following credentials to log in:

- Username: root
- Password: router's password

If the login was successful, you should be greeted with a window like this:

✘