

RUT955 Relay to Open Collector Output

[Main Page](#) > [RUT Routers](#) > [RUT955](#) > [RUT955 Hardware Application Examples](#) > **RUT955 Relay to Open Collector Output**

This section provides an example on how to connect a relay to RUT955 open collector output:



Note: some relays have internal protection diode D. When connecting such relay you mustn't mix up coil contacts. If you mix up such relay coil contacts you might cause permanent damage to the open collector output.

For more information about digital output control and RUT955 Inputs/Outputs in general refer [here](#)