

# RUTM08 Reboot

[Main Page](#) > [RUTM Routers](#) > [RUTM08](#) > [RUTM08 Manual](#) > [RUTM08 WebUI](#) > [RUTM08 System section](#) > **RUTM08 Reboot**

The information in this page is updated in accordance with firmware version [RUTM\\_R\\_00.07.08](#).



## Contents

- [1 Summary](#)

## Summary

The **Reboot** button is used only to reboot the device. Click the 'Reboot' button if you wish to reboot the device. Button can be found by pressing the marked icon:



---

After confirming, device will be rebooted.

