

# RUTM11 Reboot

[Main Page](#) > [RUTM Routers](#) > [RUTM11](#) > [RUTM11 Manual](#) > [RUTM11 WebUI](#) > [RUTM11 System section](#) > **RUTM11 Reboot**

The information in this page is updated in accordance with firmware version [RUTM\\_R\\_00.07.09](#).



## Contents

- [1 Summary](#)

## Summary

The **Reboot** button is used only to reboot the device. Click the 'Reboot' button if you wish to reboot the device. Button can be found by pressing the marked icon:



---

After confirming, device will be rebooted.

