

RUTM11 WebUI

[Main Page](#) > [RUTM Routers](#) > [RUTM11](#) > [RUTM11 Manual](#) > **RUTM11 WebUI**

Note: For WebUI supported browsers please see [Supported browsers \(RutOS\)](#).

This page contains links with descriptions of all WebUI windows of RUTM11. If you're having trouble finding this page or some of the parameters described here on your device's WebUI, you should **turn on "Advanced WebUI" mode**. You can do that by clicking the "Advanced" button, located at the top of the WebUI.



WebUI

Status	Network	Services	System
<ul style="list-style-type: none">OverviewSystemNetworkRoutesWireless (Status)ServicesRealtime DataMobile Usage	<ul style="list-style-type: none">MobileWANLANWirelessFailoverFirewallVLANRoutingTraffic ShapingPortsDHCPDNSOtherIGMP ProxyInternet StatusVRF	<ul style="list-style-type: none">Cloud SolutionsVPNMobile UtilitiesEmail RelayOPC UAModbusSerial UtilitiesDNP3Input/OutputGPSData to ServerEvents ReportingTraffic LoggingUSB ToolsHotspotWeb FilterDynamic DNSMQTTSNMPTR-069UPNPWake on LANNTRIPPython3DLMSWifi scannerOPC UA Server	<ul style="list-style-type: none">AdministrationMaintenancePackage ManagerFirmwareSetup WizardLicenseReboot