

RUTM50 Custom Scripts

Summary

The **User Scripts** function allows users to write their own shell scripts that will be executed during the device's booting process. This page is an overview of the User Scripts function in RUTM50 devices.

Startup Script

The **Startup Script** section shows the contents of the */etc/rc.local* file and allows the user to edit it. This scripts written in this file are executed at the end of the device's boot cycle. You can also execute the script via a [command line interface](#) with the following command:

```
sh /etc/rc.local
```

The figure below is an example of the Startup Script management section:

