

RUTX08 Ports

[Main Page](#) > [RUTX Routers](#) > [RUTX08](#) > [RUTX08 Manual](#) > [RUTX08 WebUI](#) > [RUTX08 Network section](#) > **RUTX08 Ports**

The information in this page is updated in accordance with firmware version [RUTX_R_00.07.08](#).



Contents

- [1 Summary](#)
- [2 Port Settings](#)
 - [2.1 All Ports](#)
 - [2.2 Port Status](#)
- [3 Port Mirroring](#)
- [4 802.1X Client](#)
 - [4.1 All Ports](#)
 - [4.2 Port Status](#)

Summary

The **Ports** page provides information related to the status of the device's physical ports, as well as the ability to edit port settings.

If you're having trouble finding this page or some of the parameters described here on your device's WebUI, you should **turn on "Advanced WebUI" mode**. You can do that by clicking the "Advanced" button, located at the top of the WebUI.



Port Settings

This section displays information about the status of the device's ports with the ability to configure port settings.

All Ports

The figure below is an example of the **All Ports** window, color indicates port speed and status:



To change port settings select port and press `edit (number of ports) ports` button:



You will be redirected to `Port settings`. From here you can enable/disable ports or change settings.



Field	Value	Description
Enable	off on; default: on	Toggle port on or off.
Auto negotiation	off on; default: on	Auto negotiation allows the device to communicate with devices on the other end of the link to determine the optimal duplex mode and speed for the port.
Link Speed	10Mbps (E) 100Mbps (FE); default: 10Mbps (E)	A measure of how fast ports are able to transmit and receive data.
Duplex	Full Half; default: Full	Bidirectional communication system that allows both end nodes to send and receive communication data or signals. Full - sends and receives simultaneously. Half - sends or receives one path at a time.
Advertisement	10M-Half 10M-Full 100M-Half 100M-Full; default: Auto	Advertises preferred duplex mode and speed for negotiation with other devices.

Port Status

This section displays port status information. There is also an option to select ports:



Port Mirroring

Port Mirroring (may also be referred to as SPAN (Switched Port Analyzer)) is a service that relays a copy of all network packets - incoming and outgoing on one Ethernet port (Source Port) to another (Monitoring Port).



Field	Value	Description
Monitoring port	Disabled LAN1 LAN2 LAN3; default: Disabled	The port which will mirror the packets.
Source port	LAN1 LAN2 LAN3; default: none	Port whose packets will be mirrored.
Enable mirroring of incoming packets	off on; default: off	
Enable mirroring of outgoing packets	off on; default: off	

802.1X Client

802.1X is a network authentication protocol that opens ports for network access when an organization authenticates a user's identity and authorizes them for access to the network. The

user's identity is determined based on their credentials or certificate, which is confirmed by the authentication server.

All Ports

The figure below is an example of the **All Ports** window, color indicates port speed and status:



To change port settings select port and press `edit (number of ports) ports` button:



You will be redirected to `Port settings`. From here you can change 802.1X settings.



Field	Value	Description
Enable	off on; default: off	Toggle 802.1x on or off.
Auth type	MD5 TLS PWD Tunneled TLS Protected EAP (PEAP) ; default: MD5	Authentication type.
Identity (Username)	string; default: none	Used as the username for authentication.
MD5, PWD, Tunneled TLS , Protected EAP (PEAP) : Password	string; default: none	Used for authentication.
TLS : CA Certificate	.crt file; default: none	Radius server CA certificate.
TLS : User certificate	.crt file; default: none	TLS client certificate.
TLS : Private Key	.key file; default: none	TLS Private Key.
TLS : Private Key Password	string; default: none	TLS Private Key Password.
Tunneled TLS : Inner authentication	PAP MSCHAP MSCHAPv2 MSCHAPv2 (no EAP) CHAP MD5 GTC; default: PAP	Inner authentication type.
Protected EAP (PEAP) : Inner authentication	MSCHAPv2 MD5 GTC; default: MSCHAPv2	Inner authentication type.
Protected EAP (PEAP) : Peap version	auto 0 1; default: auto	Peap version.
Tunneled TLS , Protected EAP (PEAP) : Anonymous identity	string; default: none	Shown as username outside the encrypted tunnel. Not used for authentication.
Tunneled TLS , Protected EAP (PEAP) : CA Certificate	.crt file; default: none	Radius server CA certificate.

Port Status

This section displays port status information. There is also an option to select ports:

