

# RUTX09 WebUI

[Main Page](#) > [RUTX Routers](#) > [RUTX09](#) > [RUTX09 Manual](#) > **RUTX09 WebUI**

---

**Note:** For WebUI supported browsers please see [Supported browsers \(RutOS\)](#).

---

This page contains links with descriptions of all WebUI windows of RUTX09. If you're having trouble finding this page or some of the parameters described here on your device's WebUI, you should **turn on "Advanced WebUI" mode**. You can do that by clicking the "Advanced" button, located at the top of the WebUI.



## WebUI

<a href="#">Status</a>	<a href="#">Network</a>	<a href="#">Services</a>	<a href="#">System</a>
<ul style="list-style-type: none"><li><a href="#">Overview</a></li><li><a href="#">System</a></li><li><a href="#">Network</a></li><li><a href="#">Routes</a></li><li><a href="#">Services</a></li><li><a href="#">Realtime Data</a></li></ul>	<ul style="list-style-type: none"><li><a href="#">Mobile</a></li><li><a href="#">WAN</a></li><li><a href="#">LAN</a></li><li><a href="#">Failover</a></li><li><a href="#">Firewall</a></li><li><a href="#">VLAN</a></li><li><a href="#">Routing</a></li><li><a href="#">Traffic Shaping</a></li><li><a href="#">Ports</a></li><li><a href="#">DHCP</a></li><li><a href="#">DNS</a></li><li><a href="#">Other</a></li><li><a href="#">IGMP Proxy</a></li><li><a href="#">Internet Status</a></li><li><a href="#">VRF</a></li></ul>	<ul style="list-style-type: none"><li><a href="#">Cloud Solutions</a></li><li><a href="#">VPN</a></li><li><a href="#">Mobile Utilities</a></li><li><a href="#">Email Relay</a></li><li><a href="#">OPC UA</a></li><li><a href="#">Modbus</a></li><li><a href="#">Serial Utilities</a></li><li><a href="#">DNP3</a></li><li><a href="#">Input/Output</a></li><li><a href="#">GPS</a></li><li><a href="#">Data to Server</a></li><li><a href="#">Events Reporting</a></li><li><a href="#">Traffic Logging</a></li><li><a href="#">USB Tools</a></li><li><a href="#">Hotspot</a></li><li><a href="#">Web Filter</a></li><li><a href="#">Dynamic DNS</a></li><li><a href="#">MQTT</a></li><li><a href="#">SNMP</a></li><li><a href="#">TR-069</a></li><li><a href="#">UPNP</a></li><li><a href="#">Wake on LAN</a></li><li><a href="#">NTRIP</a></li><li><a href="#">Python3</a></li><li><a href="#">DLMS</a></li><li><a href="#">OPC UA Server</a></li></ul>	<ul style="list-style-type: none"><li><a href="#">Administration</a></li><li><a href="#">Maintenance</a></li><li><a href="#">Package Manager</a></li><li><a href="#">Firmware</a></li><li><a href="#">Setup Wizard</a></li><li><a href="#">License</a></li><li><a href="#">Reboot</a></li></ul>