

# Speed Limit

[Main Page](#) > [FAQ](#) > [Control & Configuration](#) > **Speed Limit**

You can limit the download and upload speeds for different interface on your device with the help of the **Quality of service (QoS)** feature. The QoS page can be accessed from the device's WebUI, **Services** → **QoS** section.

You can find more detailed information in your device's manual page on QoS.

## **RUT routers**

- [RUT230 QoS](#)
- [RUT240 QoS](#)
- [RUT900 QoS](#)
- [RUT950 QoS](#)
- [RUT955 QoS](#)

## **RUTX routers**

- [RUTX08 QoS](#)
- [RUTX10 QoS](#)
- [RUTX09 QoS](#)
- [RUTX11 QoS](#)
- [RUTX12 QoS](#)
- [RUTXR1 QoS](#)

## **TRB gateways**

- [TRB140 QoS](#)
- [TRB141 QoS](#)
- [TRB142 QoS](#)
- [TRB145 QoS](#)
- [TRB245 QoS](#)
- [TRB255 QoS](#)