

# TRB142 Product Labels

[Main Page](#) > [TRB Gateways](#) > [TRB142](#) > [TRB142 Manual](#) > **TRB142 Product Labels**

The information in this page is relevant from **041** batch.

## Label/Print on the box



Information displayed after scanning QR code:

SN:9999999999;I:9999999999999999;B:999;



Information displayed after scanning SN Barcode:

9999999999



Information displayed after scanning Barcode:

4779027312385



**Text on the label/print**    **QR or Barcode equivalent**

**Description**

TRB142003000\*

-

Product code a.k.a., ordering code, displays under which product code the device was manufactured. Different product codes indicate different versions of the overall product. For example, devices with different product codes may support different LTE bands, come with different accessories, different firmware, etc.  
**\*TRB142003000** is only for standard order codes

SERIAL

SN

Serial number is a unique 10-digit device identifier. It is required when connecting the device to Teltonika's Remote Management System ([RMS](#)). The device can be added to RMS via the **System → Administration → RMS** page

IMEI

I

The IMEI (International Mobile Equipment Identity) is a unique 15 decimal digit number used to identify cellular modules. GSM network operators use the IMEI to identify devices in their networks

EAN

-

The International Article Number (a.k.a. European Article Number or [EAN](#)) is a standard describing a barcode symbology and numbering system used in global trade to identify a specific retail product type, in a specific packaging configuration, from a specific manufacturer

BATCH NO:

B

Batch number is a number that indicates the batch of materials

## Label on the product



Information displayed after scanning QR code:

SN:9999999999;I:9999999999999999;U:admin;PW:99999999;B:999;



Information displayed after scanning SN Barcode:

9999999999



**Text on the sticker**    **QR or Barcode equivalent**

**Description**

SERIAL

SN

Serial number is a unique 10-digit device identifier. It is required when connecting the device to Teltonika's Remote Management System ([RMS](#)). The device can be added to RMS via the **System → Administration → RMS** page

IMEI

I

The IMEI (International Mobile Equipment Identity) is a unique 15 decimal digit number used to identify cellular modules. GSM network operators use the IMEI to identify devices in their networks

USERNAME

U

A default value "admin" is used for product connection

PASSWORD

PW

A custom passphrase used for product connection (at least 8 characters long)

BATCH NO:

B

Batch number is a number that indicates the batch of materials