

# TRB145 Legacy FW Upgrade Instructions

[Main Page](#) > [TRB Gateways](#) > [TRB145](#) > [TRB145 Firmware Downloads](#) > **TRB145 Legacy FW Upgrade Instructions**

In order to upgrade the firmware (FW) from **TRB145X\_R\_00.01.06.1 or older** to any newer version, please follow these instructions:

1. **Find your device's Product Code.** It is on the bottom sticker of the device or on the package.
2. Depending on the Product Code, **download one of these .bin files:**
  - For codes beginning with TRB145 **0**: [TRB1450\\_R\\_00.02.03.2\\_LEGACY.bin](#)
  - For codes beginning with TRB145 **1**: [TRB1451\\_R\\_00.02.03.2\\_LEGACY.bin](#)
3. Login to your TRB145 device and **navigate to the System** → [Firmware](#) page.
4. Upload the .bin file as if it were a regular FW file and **click the 'Upgrade' button.**
5. Wait a few seconds while the file uploads. Then **click the 'Proceed' button** in the next page.

---

**After the upgrade is done, you will no longer need to follow these instructions for future upgrades.** To upgrade the firmware from TRB1\_R\_00.02.03.2 to later versions, simply download a FW file from [Firmware Downloads](#) and upgrade as usual.