

# TRB145 Reboot

[Main Page](#) > [TRB Gateways](#) > [TRB145](#) > [TRB145 Manual](#) > [TRB145 WebUI](#) > [TRB145 System section](#) > **TRB145 Reboot**

The information in this page is updated in accordance with firmware version [TRB1\\_R\\_00.07.08.1](#).



## Contents

- [1 Summary](#)

## Summary

The **Reboot** button is used only to reboot the device. Click the 'Reboot' button if you wish to reboot the device. Button can be found by pressing the marked icon:



---

After confirming, device will be rebooted.

