

# TRB245 Manual

[Main Page](#) > [TRB Gateways](#) > [TRB245](#) > [TRB245 Manual](#)

This page contains the **user manual** for TRB245 devices. Here you will find information summaries on all the features and functions available in TRB245.

- [Safety Information](#)
- [WebUI](#)
  - [Search bar](#)
  - [Status](#)
  - [Network](#)
  - [Services](#)
  - [System](#)
- Setting up your device
  - [Front & Back Panels](#)
  - [SIM Card](#)
  - [LEDs](#)
  - [Spatial Measurements & Weight](#)
- [Logging in](#)
- [Remote Monitoring & Administration](#)
- [Powering Options](#)
- [Power Consumption](#)
- [Device Recovery Options](#)
- [Product Labels](#)

For more in-depth configuration guides, visit the [TRB245 Configuration Examples](#) page.