

TRB500 Side Widget

The information in this page is updated in accordance with firmware version [TRB5_R_00.07.08.2](#)

Note: Firmware versions before TRB5_R_00.07.04.4 will not be supported by devices from batch 09 and higher..

Notice that not all provided pictures can match the information on your device.



Contents

- [1 Quick Settings](#)
- [2 System Status](#)
- [3 RMS Status](#)
- [4 Settings](#)
- [5 Overview page toggles](#)

Quick Settings

The first set of quick buttons provides options to toggle various settings on or off, allowing users to customize their preferences with ease.



System Status

The **System status** page contains information summaries about CPU, RAM, FLASH usages and router uptime.



On the top right corner is **Settings** button that transfers you to **Status System page**.

RMS Status

RMS status widget



On the top right corner is **Settings** button that transfers you to **RMS page**.

Settings

The last page is big **Settings** button that allows you quickly show or hide available settings.

Available settings for **TRB500** device:

Mobile status

System status

RMS status

Overview page toggles

If the user is on the Status Overview page, a bonus widget will appear below the side widget arrow. This setting allows the user to toggle overview page widgets and hide certain information if preferred.

