

# TSW114 LEDs

[Main Page](#) > [TSW Switches](#) > [TSW114](#) > [TSW114 Manual](#) > **TSW114 LEDs**

This wiki page contains information about TSW114 switch **LEDs** and their actions.



## Contents

- [1 Power LED](#)
- [2 Ethernet port](#)

## Power LED

The **power LED** is located on the bottom left corner of the front panel, near the power connector:



It can perform two different actions:

|                | Action | Description            |
|----------------|--------|------------------------|
| LED turned ON  |        | Switch is powered up   |
| LED turned OFF |        | Switch is not power up |

## Ethernet port

| No. | Action                     | Description                  |  |
|-----|----------------------------|------------------------------|--|
| 1   | <b>Orange</b> LED lit      | 10/100 Mbps link established |  |
| 1   | <b>Orange</b> LED blinking | Active link connection       |  |
| 2   | <b>Green</b> LED lit       | 1000 Mbps link established   |  |