# TSW304 First Start

<u>Main Page</u> > <u>TSW Switches</u> > <u>TSW304</u> > **TSW304 First Start** 

This Wiki page contains the online version of the **Quick Start Guide** (**QSG**) for the **TSW304 Switch**. Here you will find an overview of the various components found on the front and back sides of a TSW304 switch, basic hardware installation, device specifications and general safety information. It is highly recommended that you acquaint yourself with with the Quick Start Guide before using the device. If you own a TSW304 switch, you can also find a printed version of the Quick Start Guide in the device's package.



## **Contents**

- 1 Front view
- 2 Back view
- 3 Connectors
  - 3.1 2 pin power socket
- <u>4 Ethernet port</u>
- <u>5 Safety information</u>

## Front view

No.	Description	
1	Grounding screw	
2	2 pin power socket	_
3	Power LED	×
4	ETH LEDs	
5	Ethernet ports	
Bac	ck view	

×

## **Connectors**

## 2 pin power socket

The power socket is bipolar.

# **Ethernet port**

No.	Action	Describtion	
1	Orange LED lit	10/100 Mbps link established	
1	Orange LED blinking	Active link connection	×
2	<b>Green</b> LED	1000 Mbps link established	

# **Safety information**

TSW304 switch must be used in compliance with any and all applicable national and international laws and with any special restrictions regulating the utilization of the communication module in prescribed applications and environments.

#### **Technical specifications**

Input voltage range 7 - 57 VMax power consumption < 5 WMax Ethernet cable length 100 m

#### 

ĭThis sign on the package means that is necessary to read the User's Manual before you start using the device

This sign on the package means that all used electronic and electric equipment should not be mixed with general household waste