

[https://wiki.teltonika-networks.com/view/Talk:WireGuard\\_Configuration\\_Example](https://wiki.teltonika-networks.com/view/Talk:WireGuard_Configuration_Example)

## Talk:WireGuard Configuration Example

Hi, I followed the example on my RUTX11. My use case is that I want my router to connect to my remote VPN server and keep the tunnel open. Unfortunately I do not seem to be able to find out how I can trigger wireguard to start the tunnel (pinging the endpoint i.e. my remote VPN server does not seem to do anything).

Can you add instructions how to do this? Some examples on other sites seem to use a tool/script called wg-quick which I believe is not (yet) part of the wireguard-tools package.