

[https://wiki.teltonika-networks.com/view/Template:Networking\\_rut240\\_manual\\_modbus\\_modbus\\_tcp\\_set\\_parameters\\_table](https://wiki.teltonika-networks.com/view/Template:Networking_rut240_manual_modbus_modbus_tcp_set_parameters_table)

# Template:Networking rut240 manual modbus modbus tcp set parameters table

value to set	register address	register value	description
Hostname	7	Hostname	Changes hostname
Device name	71	Device name	Changes device name
Switch WiFi (ON/OFF*)	203	1   0	Turns WiFi ON or OFF
Switch mobile data connection (ON/OFF*)	204	1   0	Turns mobile data connection ON or OFF
Reboot	206	1	Reboots the router
Change APN	207	APN code	Changes APN. The number of input registers may vary depending on the length of the APN, but the very first byte of the set APN command has to be specified as <b>1</b>
Switch PIN4 state (ON/OFF*)	325	1   0	Turns PIN4 state ON or OFF