

Template:Networking rut2xx manual input output input rule table

Field	Value	Description
Enable	yes no; default: yes	Turns the input rule on or off.
Input type	Digital; default: Digital	Selects to which input pin the rule will apply.
Trigger	Low level High level Both; default: Low level	Selects which input state will trigger the rule.
Action	Send SMS Send email Change profile Turn on WiFi Turn off WiFi Reboot Activate output; default: Send SMS	<p>The action that will be taken when the rule is triggered.</p> <ul style="list-style-type: none">• Send SMS - sends an SMS message to a specified number(s) or user group. The message text is custom.• Send email - sends an email to the specified address(es). You will be prompted to enter your email account's authentication information.• Change profile - switches to using another configuration profile. Configuration profiles can be created via the <i>System</i> → <i>Profiles</i> page.• Turn on WiFi/Turn off WiFi - turns WiFi on or off.• Reboot - reboots the router when a specified amount of time passes or instantly after the trigger occurrence.• Activate output - activates the specified router output.