

https://wiki.teltonika-networks.com/view/Template:Networking_rut2xx_manual_input_output_post_get_examples_table

Template:Networking rut2xx manual input output post get examples table

Action	POST/GET URL
Turn output on	http://192.168.1.1/cgi-bin/output?username=user1&password=user1&action=on&pin=oc
Turn output off	http://192.168.1.1/cgi-bin/output?username=user1&password=user1&action=off&pin=oc
Turn output on after a 10 second delay	http://192.168.1.1/cgi-bin/output?username=user1&password=user1&action=on&pin=oc&delay=10
Turn output on for 5 seconds	http://192.168.1.1/cgi-bin/output?username=user1&password=user1&action=on&pin=oc&time=5
Turn output on for 5 seconds after a 10 second delay	http://192.168.1.1/cgi-bin/output?username=user1&password=user1&action=on&pin=oc&delay=10&time=5
Turn Digital 4 PIN output on	http://192.168.1.1/cgi-bin/output?username=user1&password=user1&action=on&pin=4pin
Turn Digital 4 PIN output off	http://192.168.1.1/cgi-bin/output?username=user1&password=user1&action=off&pin=4pin