

https://wiki.teltonika-networks.com/view/Template:Networking_rut900_manual_modbus_modbus_tcp_get_parameters_table

Template:Networking rut900 manual modbus modbus tcp get parameters table

	required value	register number	number of registers	representation
System uptime		1	2	32 bit unsigned integer
Mobile signal strength (RSSI in dBm)		3	2	32 bit integer
System temperature (in 0.1 °C)		5	2	32 bit integer
System hostname		7	16	Text
GSM operator name		23	16	Text
Router serial number		39	16	Text
LAN MAC address		55	16	Text
Router name		71	16	Text
Currently active SIM card slot		87	16	Text
Network registration info		103	16	Text
Network type		119	16	Text
Current WAN IP address		139	16	32 bit unsigned integer