

# Template:Networking rut900 manual modbus modbus tcp set parameters table

value to set	register address	register number	register value	description
Switch WiFi (ON/OFF*)	210	211	1   0	Turns WiFi ON or OFF
Switch mobile data connection (ON/OFF*)	211	212	1   0	Turns mobile data connection ON or OFF
Switch SIM card	212	213	1   2   0	Changes the active SIM card slot <ul style="list-style-type: none"><li>• 1 - switch to SIM1</li><li>• 2 - switch to SIM2</li><li>• 0 - switch from the the SIM card opposite of the one currently in use (SIM1 → SIM2 or SIM2 → SIM1)</li></ul>
Change APN	213	214	APN code	Changes APN. The number of input registers may vary depending on the length of the APN, but the very first byte of the set APN command denotes the number of the SIM card for which to set the APN. This byte should be set to: <ul style="list-style-type: none"><li>• 1 - to set APN for SIM1</li><li>• 2 - to set APN for SIM2</li></ul>
Reboot	220	221	1	Reboots the router