

# Template:Networking rutos manual reset settings

## Reset settings

The **Reset settings** page is used for restoring device's configuration.



Reset type	Value	Description
System settings	-(single select)	Resets all configuration except RMS data, mdcollect database, logs and PIN code.
Factory defaults	-(single select)	Resets device to factory configuration.
User's default configuration*	-(single select)	Resets device to user's default configuration.

\*This button will be greyed out until you have created a

**[[{{name}}\_Maintenance#Create\_user's\_default\_configuration|User's default configuration]].**

## Create user's default configuration

The **Create user's default configuration** section is used to create or delete a file which stores current device configuration. The default configuration can later be loaded in **[[{{name}}\_Maintenance#Reset\_settings|Reset settings]]** page or via reset button.

Click the 'Create' button to generate default configuration file from your current device configuration.

