

https://wiki.teltonika-networks.com/view/Template:Networking_rutx11_manual_remote_management_options_table

Template:Networking rutx11 manual remote management options table

Remote control method	Can get parameters	Can set parameters
[[{{name}}_Remote_Monitoring_%26_Administration#RMS RMS]]	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
[[{{name}}_Remote_Monitoring_%26_Administration#SSH_access SSH]]	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
[[{{name}}_Remote_Monitoring_%26_Administration#HTTP_access HTTP]]	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
[[{{name}}_Remote_Monitoring_%26_Administration#SMS SMS]]	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
[[{{name}}_Remote_Monitoring_%26_Administration#VPN VPN]]	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
[[{{name}}_Remote_Monitoring_%26_Administration#SNMP SNMP]]	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
[[{{name}}_Remote_Monitoring_%26_Administration#Modbus_TCP Modbus TCP]]	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
[[{{name}}_Remote_Monitoring_%26_Administration#MQTT MQTT]]	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
[[{{name}}_Remote_Monitoring_%26_Administration#TR-069 TR-069]]	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>