

Template:Networking rutx14 manual remote management options table

| Remote control method | Can get parameters | Can set parameters |
|---|-------------------------------------|-------------------------------------|
| [[{{{name}}}_Remote_Monitoring_%26_Administration#RMS RMS]] | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| [[{{{name}}}_Remote_Monitoring_%26_Administration#SSH_access SSH]] | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| [[{{{name}}}_Remote_Monitoring_%26_Administration#HTTP_access HTTP]] | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| [[{{{name}}}_Remote_Monitoring_%26_Administration#SMS SMS]] | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| [[{{{name}}}_Remote_Monitoring_%26_Administration#VPN VPN]] | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| [[{{{name}}}_Remote_Monitoring_%26_Administration#SNMP SNMP]] | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| [[{{{name}}}_Remote_Monitoring_%26_Administration#Modbus_TCP Modbus TCP]] | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| [[{{{name}}}_Remote_Monitoring_%26_Administration#MQTT MQTT]] | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| [[{{{name}}}_Remote_Monitoring_%26_Administration#TR-069 TR-069]] | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |