

# Template:Networking rutxxx manual overview mobile widget signal strength indicator

<b>bars</b>	<b>signal strength value / RSSI (in dBm)</b>
0	$\leq -111$
1	-110 to -97
2	-96 to -82
3	-81 to -67
4	-66 to -52
5	$\geq -51$