

[https://wiki.teltonika-networks.com/view/Template:Networking\\_trb140\\_manual\\_supported\\_frequency\\_bands\\_table](https://wiki.teltonika-networks.com/view/Template:Networking_trb140_manual_supported_frequency_bands_table)

# Template:Networking trb140 manual supported frequency bands table

Product code	Region (operator) <sup>1</sup>	Supported bands
TRB140 0*****	Europe <sup>2</sup> , the Middle East, Africa, Korea, Thailand, India, Malaysia	<ul style="list-style-type: none"><li><b>4G (LTE-FDD):</b> B1 (2100 MHz), B3 (1800 MHz), B7 (2600 MHz), B8 (900 MHz), B20 (800 MHz), B28A (700 MHz)</li><li><b>4G (LTE-TDD):</b> B38 (2600 MHz), B40 (2300 MHz), B41 (2500 MHz)</li><li><b>3G:</b> B1 (2100 MHz), B8 (900 MHz)</li><li><b>2G:</b> B3 (1800 MHz), B8 (900 MHz)</li></ul>
TRB140 1*****	South America, Australia, New Zealand, Taiwan, Malaysia	<ul style="list-style-type: none"><li><b>4G (LTE-FDD):</b> B1 (2100 MHz), B2 (1900 MHz), B3 (1800 MHz), B4 (1700 MHz), B5 (850 MHz), B7 (2600 MHz), B8 (900 MHz), B28 (700 MHz)</li><li><b>4G (LTE-TDD):</b> B40 (2300 MHz)</li><li><b>3G:</b> B1 (2100 Mhz), B2 (1900 Mhz), B5 (850 Mhz), B8 (900 Mhz)</li><li><b>2G:</b> B2 (1900 MHz), B3 (1800 MHz), B5 (850 MHz), B8 (900 MHz)</li></ul>

<sup>1</sup> Versions for other regions are under development.

<sup>2</sup> Regional availability - excluding Russia & Belarus.