

Template:Networking trb145 manual rs485 pinout

RS485 connector pinout

Pin	Name	Description
1	D_N	Driver negative signal
2	R_N	Receiver negative signal
3	GND	Device ground
4	D_P	Driver positive signal
5	R_P	Receiver positive signal
6	Vin	Power input 9-30 VDC

