

https://wiki.teltonika-networks.com/view/Template:Networking_trm_manual_powering_options_power_socket

Template:Networking trm manual powering options power socket

This device has a USB connector and is powered via a micro USB cable. Operating Voltage - 5V.

