

# Template:Rut240 connection status leds table

The LED displays the router's current connection state and network type among a few other things:

<b>ACTION</b>	<b>DESCRIPTION</b>
<b>2G, 3G and 4G LEDs blinking every 1 second</b>	No SIM or bad PIN
<b>Blinking from 2G LED to 4G LED repeatedly</b>	Attempting to connect to a mobile network operator
<b>2G/3G/4G LED blinking every 1 sec</b>	Connected to 2G/3G/4G, no data session established
<b>2G/3G/4G LED turned on</b>	Connected to 2G/3G/4G with data session
<b>2G/3G/4G LED blinking rapidly</b>	Connected to 2G/3G/4G with data session and data is being transferred