RUT230 Reboot

The information in this page is updated in accordance with firmware version **RUT2_R_00.07.03.4**.

Notice: *This device has entered it's EOL (End of Life) cycle. For more information, visit our EOL policy here. Temporarily, some content in this page might not match features found in firmware listed above.*

***Note**: **click here** for the old style WebUI (FW version RUT2XX_R_00.01.14.7 and earlier) user manual page.*

□

Contents

- 1 Summary

Summary

The **Reboot** button is used only to reboot the device. Click the 'Reboot' button if you wish to reboot the device. Button can be found by pressing the marked icon:



After confirming, device will be rebooted.

