

RUT240 Relay to Open Collector Output

[Main Page](#) > [RUT Routers](#) > [RUT240](#) > [RUT240 Hardware Application Examples](#) > **RUT240 Relay to Open Collector Output**

This page provides an example on how to connect a relay to a RUT240 device's open collector output.



Note: if you use different power supplies for RUT240 and relay, their ground wires must be connected together.

Note: some relays have internal protection diode D. When connecting such relay you mustn't mix up coil contacts. If you mix up the relay coil contacts you might cause permanent damage to the open collector output.

See also

- [Input/Output Manual page](#)
- [Power connector pinout](#)