RUT906 BACnet

<u>Main Page > RUT Routers > RUT906 > RUT906 Manual > RUT906 WebUI > RUT906 Services section > RUT906</u> BACnet

The information in this page is updated in accordance with firmware version **RUT9M_R_00.07.07.1**.

Contents

- <u>1 Summary</u>
- <u>2 General Configuration</u>
- <u>3 BIP Configuration</u>
- <u>4 MSTP Configuration</u>

Summary

BACnet is a communication protocol for building automation and control (BAC) networks that use the ASHRAE, ANSI, and ISO 16484-5 standards protocol.

This manual page provides an overview of the BACnet functionality in RUT906 devices.

Note: BACnet is additional software that can be installed from the **System** \rightarrow **<u>Package Manager</u>** page.

General Configuration

×

Field	Value	Description
Enable	off on; default: off	Enables BACnet router function.
Enable BBMD	off on; default: off	Enables BACnet broadcast management function.
BBMD interface	network interface; default: eth0	Specifies interface for BBMD function. IP address of this interface should be reachable from WAN.
Allow Remote Access	off on; default: off	Creates port forward firewall rule to make application port in LAN reachable from selected BBMD interface.
Force gateway	off on; default: off	Adds configured gateway IP address and port to BBMD packages sent.
Gateway address	ip4; default: none	Gateway IP address.
Gateway port	integer [165535]; default: none	Gateway port number.

BIP Configuration

Communications in BACnet over IP (**BIP**) rely upon the protocol rules of IP and Ethernet.

×

Field Value Description

BIP port integer [1..65535]; default: 47808 BIP UDP port.

MSTP Configuration

MSTP is most commonly used to connect field devices to controllers / routers / control applications. The physical layer uses RS485 which allows up to 31 devices to be installed on a single network.

×

Field	Value	Description
MSTP MAC	integer [0127]; default: 13	Router MSTP MAC address.
MSTP MAC max	integer [1127]; default: 127	Maximum client address in the MSTP network.
Baud rate	300 600 1200 2400 4800 9600 19200 38400 57600 115200 230400; default: 38400	Serial data transmission rate (in bits per second).
Parity	Even Odd Mark Space None; default: None	 In serial transmission, parity is a method of detecting errors. An extra data bit is sent with each data character, arranged so that the number of 1 bits in each character, including the parity bit, is always odd or always even. If a byte is received with the wrong number of 1s, then it must have been corrupted. However, an even number of errors can pass the parity check. None (N) - no parity method is used. Odd (O) - the parity bit is set so that the number of "logical ones (1s)" has to be odd. Even (E) - the parity bit is set so that the number of "logical ones (1s)" has to be even. Space (S) - the parity bit will always be a binary 0. Mark (M) - the parity bit will always be a binary 1.
Data bits	5 6 7 8; default: 8	Number of data bits for each character.
Stop bits	1 2; default: 1	Stop bits sent at the end of every character allow the receiving signal hardware to detect the end of a character and to resynchronise with the character stream. Electronic devices usually use one stop bit. Two stop bits are required if slow electromechanical devices are used