

RUT951 WebUI

[Main Page](#) > [RUT Routers](#) > [RUT951](#) > [RUT951 Manual](#) > **RUT951 WebUI**

Note: For WebUI supported browsers please see [Supported browsers \(RutOS\)](#).

This page contains links with descriptions of all WebUI windows of RUT951. If you're having trouble finding this page or some of the parameters described here on your device's WebUI, you should **turn on "Advanced WebUI" mode**. You can do that by clicking the "Advanced" button, located at the top of the WebUI.



WebUI

Status	Network	Services	System
<ul style="list-style-type: none">OverviewSystemNetworkRoutesWireless (Status)ServicesRealtime DataMobile Usage	<ul style="list-style-type: none">MobileWANLANWirelessFailoverFirewallVLANRoutingTraffic ShapingPortsDHCPDNSOtherIGMP Proxy	<ul style="list-style-type: none">Cloud SolutionsVPNMobile UtilitiesEmail RelayOPC UAModbusDNP3Input/OutputData to ServerEvents ReportingTraffic LoggingHotspotWeb FilterDynamic DNSMQTTSNMPTR-069UPNPWake on LANDLMSOPC UA Server	<ul style="list-style-type: none">AdministrationMaintenancePackage ManagerFirmwareSetup WizardLicenseReboot