

RUT956 WebUI

[Main Page](#) > [RUT Routers](#) > [RUT956](#) > [RUT956 Manual](#) > **RUT956 WebUI**

Note: For WebUI supported browsers please see [Supported browsers \(RutOS\)](#).

This page contains links with descriptions of all WebUI windows of RUT956. If you're having trouble finding this page or some of the parameters described here on your device's WebUI, you should **turn on "Advanced WebUI" mode**. You can do that by clicking the "Advanced" button, located at the top of the WebUI.



WebUI

Status	Network	Services	System
<ul style="list-style-type: none">OverviewSystemNetworkRoutesWireless (Status)ServicesRealtime DataMobile Usage	<ul style="list-style-type: none">MobileWANLANWirelessFailoverFirewallVLANRoutingTraffic ShapingPortsDHCPDNSOtherIGMP Proxy	<ul style="list-style-type: none">Cloud SolutionsVPNMobile UtilitiesEmail RelayOPC UAModbusSerial UtilitiesDNP3Input/OutputGPSData to ServerEvents ReportingTraffic LoggingUSB ToolsHotspotWeb FilterDynamic DNSMQTTSNMPTR-069UPNPWake on LANNTRIPPython3DLMSOPC UA Server	<ul style="list-style-type: none">AdministrationMaintenancePackage ManagerFirmwareSetup WizardLicenseReboot