

RUTX08 Front & Back Panels

[Main Page](#) > [RUTX Routers](#) > [RUTX08](#) > [RUTX08 Manual](#) > **RUTX08 Front & Back Panels**

This page provides descriptions of the components found on the **front** and **back** panels of a RUTX08 device. For more information about connectors, visit [Serial Utilities](#) and [Input/Output](#) pages.

□

Contents

- [1 Front panel](#)
- [2 Back panel](#)
- [3 Power socket pinout](#)

Front panel



Back panel



Power socket pinout

