

RUTXR1 WebUI

[Main Page](#) > [RUTX Routers](#) > [RUTXR1](#) > [RUTXR1 Manual](#) > **RUTXR1 WebUI**

Note: For WebUI supported browsers please see [Supported browsers \(RutOS\)](#).

This page contains links with descriptions of all WebUI windows of RUTXR1. If you're having trouble finding this page or some of the parameters described here on your device's WebUI, you should **turn on "Advanced WebUI" mode**. You can do that by clicking the "Advanced" button, located at the top of the WebUI.



WebUI

Status	Network	Services	System
<ul style="list-style-type: none">OverviewSystemNetworkRoutesWireless (Status)ServicesRealtime DataMobile Usage	<ul style="list-style-type: none">MobileWANLANWirelessFailoverFirewallVLANRoutingTraffic ShapingPortsDHCPDNSOtherIGMP ProxyInternet StatusVRF	<ul style="list-style-type: none">Cloud SolutionsVPNMobile UtilitiesEmail RelayOPC UAModbusSerial UtilitiesDNP3Data to ServerEvents ReportingTraffic LoggingUSB ToolsHotspotWeb FilterDynamic DNSMQTTSNMPTR-069UPNPWake on LANNTRIPPython3DLMSOPC UA Server	<ul style="list-style-type: none">AdministrationMaintenancePackage ManagerFirmwareSetup WizardLicenseReboot