

RUTXR1 Wifi scanner

[Main Page](#) > [RUTX Routers](#) > [RUTXR1](#) > [RUTXR1 Manual](#) > [RUTXR1 WebUI](#) > [RUTXR1 Services section](#) > **RUTXR1 Wifi scanner**

The information in this page is updated in accordance with firmware version [RUTX_R_00.07.07.1](#).

WiFi Scanner

The **WiFi Scanner** provides you with the possibility to scan and collect information about connected devices and surrounding access points. The collected data is sent using the [Data to Server](#) functionality.



Field	Value	Description
Enable 2.4GHz	off on; default: off	Enables or disables WiFi scanner.
Enable 5GHz	off on; default: off	Enables or disables WiFi scanner.
Interval	integer; default: 10	Interval between scans in seconds.