

TRB255 Reboot

[Main Page](#) > [TRB Gateways](#) > [TRB255](#) > [TRB255 Manual](#) > [TRB255 WebUI](#) > [TRB255 System section](#) > **TRB255 Reboot**

The information in this page is updated in accordance with firmware version [TRB2_R_00.07.08](#).



Contents

- [1 Summary](#)

Summary

The **Reboot** button is used only to reboot the device. Click the 'Reboot' button if you wish to reboot the device. Button can be found by pressing the marked icon:



After confirming, device will be rebooted.

